

INSTRUCTION MANUAL PERSONAL BLENDER

T-626



Please read this booklet carefully before fixing and using
And save it for future reference

IMPORTANT SAFEGUARDS

READ THESE INSTRUCTIONS BEFORE USE

- The necessary precautions must be taken when using electrical appliances, and these include the following:
1. Make sure that the voltage on the appliance rating plate corresponds to that of the mains electricity.
 2. Never leave the appliance unattended when connected to the power supply; unplug it after every use.
 3. Never place the appliance on or close to sources of heat.
 4. Always place the appliance on a flat, level surface during use.
 5. Never leave the appliance exposed to the elements (rain, sun, etc...).
 6. Make sure that the power cord does not come into contact with hot surfaces.
 7. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge only if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Do not allow children to play with the appliance. Cleaning and user maintenance must not be carried out by children unless they are older than 8 and supervised.
 8. Children under age 8 should not be allowed to handle appliance and its power cord which must be kept out of their reach.
 9. Never place the appliance body, plug or power cord in water or other liquids; always wipe clean with a damp cloth.
 10. Always unplug the power cord from the electricity mains before fitting or removing single attachments or before cleaning the appliance.
 11. Always make sure that your hands are thoroughly dry before using or adjusting the switches on the appliance, or before touching the power plug or power connections.
 12. To unplug the appliance, grip the plug and remove it directly from the power socket. Never pull the power cord to unplug the appliance.
 13. Do not use the appliance if the power cord or plug are damaged or if the appliance itself is faulty; all repairs, including substitution of power cord.
 14. In case of using extension leads, these must be suitable for the appliance power to avoid danger to the operator and for the safety of the environment in which the

- appliance is being used. Extension leads, if not suitable, can cause operating anomalies.
15. Never allow the cord to dangle in places where it may be grabbed by a child.
 16. Do not threaten the safety of the appliance by using parts that are not original or which have not been approved by the manufacturer.
 17. Any changes to this product that have not been expressly authorised by the manufacturer may lead to the user's guarantee being rendered null and void.
 18. In the event that you decide to dispose of the appliance, we advise you to make it inoperative by cutting off the power cord. We also recommend that any parts that could be dangerous be rendered harmless, especially for children, who may play with the appliance or its parts.
 19. Packaging must never be left within the reach of children since it is potentially dangerous.
 20. NEVER TOUCH MOVING PARTS.
 21. The blades are sharp, take great care while emptying the container and when cleaning.
 22. Never operate the appliance while it is empty.
 23. Do not use the appliance if the blade is damaged.
 24. Do not use the appliance to chop foods that are excessively hard (e.g., meat on the bone).
 25. Leave hot liquids to cool before pouring them into the container.
 26. PREPARE THE CONTAINER CORRECTLY WITH THE FOODS TO BE BLENDED AND THE BLADE SET BEFORE CLOSING IT AND FITTING IT TO THE POWER BASE.
 27. Before removing the container with the blade set from the power base, wait for the blade to stop moving completely.
- DO NOT THROW AWAY THESE INSTRUCTIONS

DESCRIPTION OF PARTS

- A Container lid
- B Power base
- C Container
- D Drink lid
- E Blade set
- F Button



This appliance has been designed for HOME USE ONLY and must not be used for commercial and industrial purposes.

IMPORTANT NOTE:

Before using the appliance, we recommend washing all removable parts that will come into contact with food. Use hot water, a cloth and a mild detergent. Dry thoroughly.

- Place the container (C) on a flat, horizontal surface with the opening facing upwards and pour in the ingredients you wish to use, cutting them into small pieces, if necessary and without exceeding the maximum level mark on the container itself.
- Place the blade set (E) on the opening of the container (C) and turn it clockwise until it locks into place.
- Turn the container (C) upside down and place it in the slot (A) on the power base (B) making sure that the arrows on the base meet up with those on the blade set (E).
- Plug the appliance into the power mains.
- Pressing button (F) will start the blender, which will continue to operate for as long as it is pressed.

- After using, unplug the appliance and wait for the blade set to stop before removing the container (C) from the power base (B).
- Turn the container (C) upright and place it on a flat surface.
- To open the container, unscrew the blade set (E).
- Pour the contents into a glass or fit the container (C) with the special lid (D) to carry it round through out the day.
- Wash the container (C) after use.

Prepare the container (C) with the ingredients for blending and close it correctly with the blade set (E) before fitting it to the power base (B) and plugging it into the mains power.

The blades are sharp; handle with care.

Do not leave the appliance running for more than 30 seconds.

Brief pulses of a few seconds each are best.

Never place hot liquids or fruit with stones or shells inside the container (C) as they could damage the blade.

HELPFUL HINTS

- Insert liquids into the container first, unless the recipe states otherwise.
- Cut hard fruit and vegetables into pieces from 1.8 to 2.5 cm in size.
- Do not overfill the container (C). If the power base blocks, switch off the blender immediately, unplug it and leave it to cool for at least 15 minutes. Remove the excess ingredients and continue to blend.
- This appliance cannot be used to mash potato or to whisk egg whites or dairy products, nor firm dough or mince raw meat.
- For the best results, add the ingredients in the following order: liquids, fresh ingredients, frozen fruit, yoghurt and ice cream.

CLEANING

IMPORTANT NOTE
Unplug the appliance and make sure that the blades have stopped moving before cleaning the appliance. The blades are sharp; take care when cleaning.

- Wipe the power base (B) clean with a damp cloth. Do not use abrasive products.
- TECHNICAL DATA**
Power: 300W
Power supply: 220-240V-50Hz