

## CLEANING AND CARE

**IMPORTANT:** BEFORE CLEANING PLEASE ENSURE THAT THE COOKING PLATES HAVE FULLY COOLED!

- Always turn off the power and remove the plug from the mains outlet before & after cleaning. Ensure that the appliance has fully cooled before cleaning to avoid burns!
- The cooking plates are coated with non-stick cooking surface. Therefore little cleaning is required. Simply wipe cooking plates over with a damp cloth.
- Do not immerse the sandwich maker in water or other liquids.
- Do not use abrasive scouring pads, powders or cleaners.
- Do not place in the dishwasher.
- Before next use, lightly grease the cooking plates for easy removal of sandwiches etc.

## STORAGE

- Always unplug the sandwich maker before storage.
- Always make sure the sandwich maker is cool and dry before storing.
- To minimize storage space in your kitchen, the sandwich maker can be stored vertically.

## SPECIFICATION:

220-240V~50/60Hz  
POWER: 1400W

4



# HomeElectric SANDWICH MAKER INSTRUCTION MANUAL

Model: HG-279



Please read these instructions carefully and retain for future reference.

2

## IMPORTANT SAFEGUARDS & WARNINGS

### READ ALL INSTRUCTIONS BEFORE USE

- Make sure the voltage in your outlet matches the voltage indicated on the appliance's rating label!
- Always turn the power switch off at the power outlet before you insert or remove a plug. Remove by grasping the plug – do not pull on the cord.
- Turn the power off and remove the plug when the appliance is not in use and before cleaning.
- Do not use your appliance with an extension cord unless this cord has been checked and tested by a qualified technician or service person.
- Close supervision is necessary when your appliance is being used by children or infirm persons.
- Young children should be supervised to ensure that they do not play with the appliance. Children should not play with this appliance. This is not a toy!
- Never leave the appliance unattended while in use. Always unplug from mains outlet when not in use.
- Do not use the appliance for any purpose other than its intended use.
- Do not place an appliance on or near a hot gas flame, electric element or any heat source.
- Do not let the power cord of an appliance hang over the edge of a table or bench top or touch any hot surfaces.
- Do not operate any appliance with a damaged power cord or plug. In order to avoid the risk of an electric shock, never try to repair the appliance yourself! Take it to an authorized service agent for examination and repair. Always inspect the appliance for any visual damage before first use.
- Do not use outdoors or for commercial purposes.
- Unplug the unit when finished using. Never leave plugged in.
- Do not immerse the appliance in water or any other liquid.
- **WARNING**—This appliance will get HOT! When in use please take extra care not to touch the cooking plates when the appliance is operational! Also keep young children well away at all times to avoid danger of burns!
- This appliance is not intended for use by persons (including children) with reduced physical sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

### BEFORE THE FIRST USE

- Remove all packaging materials carefully.
- Clean the baking plates with a damp cloth or sponge.
- Slightly grease the baking plates with a little cooking oil.
- Take care to prevent water from running into the appliance.

## PARTS IDENTIFICATION

Before using your Sandwich Maker for the first time, you should become familiar with all of the parts. Read all Instructions and Safeguards carefully!



1. Upper Housing
2. Power Indicator
3. Ready Indicator
4. Upper Plate
5. Bottom Housing
6. Handle Lock
7. Bottom Plate
8. SUS Decoration sheet

## USING YOUR SANDWICH MAKER

Before using the appliance for the first time, peel off any promotional materials and packaging materials, and check that the cooking plates are clean and free of dust. If necessary, wipe over with a damp cloth. For best results, pour a teaspoon of vegetable oil on to the non-stick plates. Spread over with an absorbent kitchen towel and wipe off any excess oil. Ensure the sandwich maker is positioned on a flat even surface away from any other heat sources and easily accessible!

When your sandwich maker is heated for the first time, it may emit slight smoke or odor. This is normal with many heating appliances. This does not affect the safety of your appliance. The smell will eventually dissipate.

- Insert the plug into the power outlet, you will notice that the power indicator will turn on, indicating that the sandwich maker has begun preheating.
  - Allow your sandwich maker to preheat until the ready indicator goes on. This indicates that the cooking plates have reached the correct temperature for cooking.
  - For best results, lightly spray the cooking plates with a cooking oil spray before using. This will assist in the removal of the sandwiches after cooking.
  - Divide mixture into pan holes as per recipes using a jug & spoon or fabric piping bag.
- Note:** Do not use disposable plastic piping bags as these may melt if they come into contact with hot plates.
- Gently close the lid. Do not slam the lid down as it may cause the mixture to run off the cooking plates.
  - Allow to cook for approximately 3-5 minutes or until golden.
  - To remove sandwiches always use a plastic or wooden spatula. Never use a sharp object or metal tools, as this will damage the non-stick surface of the cooking plates.

3