

QUARTZ HEATER

Model:HK-4515



220-240V~ 50Hz/60Hz 1500W INSTRUCTION MANUAL

1. FEATURES

- 1. Feel warm at all angles
- Fashionable design
- 3. Warms up quickly
- Instant heat accompanied by a cozy glowing light
- Select between different heating powers.

2. TECHNICAL DATA

Model	Spec.	Voltage/Frequency	1		
HK-4515	3tubos	220 240V	Package(mm)	Power(w)	N.W/G.W(kg
	ottabes	220-240V~50Hz/60Hz	475X227X352	150011	TATAL WIE
. OPERA	TING INS	TRUCTIONS	110M221M332	1500W	2.5/3.0

- 1. Remove the packaging and make sure that the appliance is intact.
- 2. The appliance must always be placed on a firm and leveled surface and insert the both feet into the hole of the appliance at back before use
- 3. Insert the power cord and always make sure the heater is placed on a firm and level surface, otherwise the safety anti tilt switch may inadvertently operate.
- 4. Turn on the heater by pressing either of the two rocker switches on the front of the heater to cause the elements to light. When one element is lit, the heater is giving out 500W, when two elements is lit, the heater is giving out1500W.
- After use, always ensure that the heater is switched off and unplugged from the main supply.
- 1. The appliance must always be placed on a firm and leveled surface and make sure that heater
- 2. Always check that there is nothing flammable in front of or to the rear and sides of the heater, and always make sure that nothing can either drop or fall onto the heater. Make sure that nothing which may melt is placed too close to the heater. Always make sure that there are no flammable liquids or materials in the immediate vicinity of the heater.
- 3. Never use the heater in wet or damp conditions such as shower room, bathroom, or anywhere near a swimming pool, hot tub or Jacuzzi.
- The correct operation of the appliance is obtained when the heater is placed vertically.
- 5. When the appliance is not in use switch it off and unplug it.
- 6. Never use the heater outdoors.
- 7. Never leave the heater unattended for any period of time or if there are children or animals
- 8. Before cleaning the heater or carrying out any maintenance, switch off and unplug the heater. Never use water to clean the heater or allow water to spill onto it as this may cause a short 5. MAINTENACE

- The appliance only needs an external cleaning.
- After use and before cleaning always unplug the appliance and wait until it cools down.
- 4. Please use a moistened cloth to clean painted parts, do not use any other solvents.

- 1. The heater must not be located immediately below a socket outlet.
- 2.Do not use this heater with a programmer, timer, separate remote-control system or any

other device that switches the heater on automatically, since a fire risk exists if the heater is covered or positioned incorrectly.

- 3.Do not use this heater in the immediate surroundings of a bath, a shower or a swimming
- 4. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety
- 5. Children should be supervised to ensure that they do not play with the appliance
- 6. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

اولا:- المزايــــ

1. الشعور بالمرارة من جميع الزوايا

2. تصميم عصري

3. ارتفاع درجة حرارة من جميع الزاويا بشكل سريع

4. يراقق ارتقاع الحرارة ضوة خقيف

5. الاختيار السهل بين مختلف درجات الحرارة

ثانيا: - المواصفات التقنية

الوزن	الواطية	القياسات	القولتية الهيرنزية	المواصلة	the each
2.5/3.0	1500W	475X227X352	220-240V~50Hz/60Hz	3	HK-4515

ثالث :- ارشادات التشغيل

1. ازالة التظيف والتاكد من أن شمعات الجهاز سليمة.

2. يجب التكد من ان كل اجزاء الجهاز مركبة يشكل صحيح وايضا تركيب اقدام الجهاز بالمكان المخصص لها.

3. يجب التاكد من المدفاء موضوعة على سطح مستقيم قبل التشغيل لان عكس ذلك سوف يصل جهاز قطع التيار الكهربائي .

ق. لتشغل الجهاز يجب الشقط على ازرار التشغل الموجودة في اعلى الجهاز . عقد تشغل شمعة واحدة قان الجهاز سوف يستهلك 200 واطر عند تشغل اللبن شمعة قان الجهاز سوف يستهلك 1500 واطر عقد تشغل ثلاث شمعات قان الجهاز سوف يستهلك 4500 م

بعد الاستحمال يجب الناكد من الجهاز مظل ومقصول عن مصدر التيار الرئيسي.

رابعا :- تتبي

1. يجب دائما وضع الجهاز على مكان مستقيم عد التشغيل ويمكان يمكن رؤيته من جميع الجهات.

2. دائما التحقق من أنه لا يوجد اي شي قابل للاشتعال قرب الجهاز ومن جميع الاتجاهات والتلكد من عدم سقوط اي شي على الجهاز

والتلكد من عدم وجود مواد قابلة للأويان قرب الجهاز . 3. عدم استكدام الجهاز بالإماكن الرطبة والميللة مثل غرف الاستحمام او حمام المبياحة او الجاكوزي .

4. يجب وضع الجهاز يصورة عامودية للمصول على العمل الصحيح للجهاز

5. عدما يكون الجهاز ليس قيد الاستخدام يجب اطفاء الجهاز وقصل التيار الكهرياني.

6. عدم استخدام الجهاز بالهواء الطلق .

7. لا تترك الجهاز بعيدا على المراقبة وخصوصا اذا كان هذاك اطقال او هيوانات قرب الجهاز.

8. قبل تنظيف الجهاز أو القيام بأي من أحمال الصياة، يجب إيقاف وقصل الجهاز من التيار الكهرياني و عدم استخدام الماء لتنظيف الجهاز الان ذلك يميب حدوث ماس كهريائي مما يزدي الى حدوث حريق .

خامسا: - نصاتح للتنظيف

1. الجهاز بحتاج فقط الى تقطيف خارجي.

2. قبل تتظیف الجهاز احرس دائما على أصل الجهاز وانتظر حتى بيرد.

3. تتظیف الیوایات من الغیار

4. الرجاء استخدام قطعة قماش مبللة قليلا لتنظيف الاجزاء الخارجية و لا تستخدم أي منظفات أخرى.

سائسا: - تحذير

1. لا تشغل الجهاز الا من مصدر التيار الكهرياني الرئيسي وعدم استخدام اي وصلات الحرى.

2. لا تستطيع هذا الجهاز مع اي من نظم للتشغيل و عدم التشغيل انتلقائي عن بعد او اي انظمة تشغيل مباشرة بدون المراقبة لكي لا تحصل حوادث الحريق لا سلمح الله .

لا تستخدم هذه الجهاز في المحيط المياشر للحمام، أو حمام السياحة.

 ق. حدم استخدام هذا الجهاز من قبل اشخاص غير مؤهلين (يمن قبهم الأطفال) او اشخاص لديهم النفاة بالقدرات الجمدية والحمية والطلية، أو حدم وجود الفيرة والمعرفة، إلا إذا حصلوا على إشراف أو تطيمات بخصوص استخدام الجهاز من قبل شخص

مسؤول عن سلامتهم.

5. يجب التاكد دائما بان الاطقال لا تلعب بالجهاز مطلقا .

6. في حالة تلف سلك التيار الكهريائي ، لا يد من استيدالها من قبل الشركة المصنعة، أو وكيل القدماتها أو الأشفاص المؤهلون وذلك من أجل تجنب المفاطر.