

## INSECT KILLER

The insect killer is used to attract the flying insects by black light, such as flies, moths, mosquitoes, and other flying insects, and then the electrically charged, high voltage metal grids will electrocute the insects.


The insect killer series have thin and modern style, high efficiency and safety, with non-clogging killing grid, non-rust, cracked or fade surface. The special designed black light tube ( ultra-violet rays ) is completely harmless to human bodies and pets.

Outer mesh protects human from touching the grids.

No chemicals involved in it, no fumes, no smell, no sprays, no mess, and pollution free.


The insect killer series are ideal for indoor use, such as houses, factories, food shops, butcher' storage, hospitals, etc.

### WARNINGS:


- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
  - The appliance is indoor use only. The appliance is not suitable for use in barns, stables and similar locations.
  - The appliance is not to be used in locations where flammable vapors or explosive dust is likely to exist.
  - Hang or mount the appliance on a place where children can't reach. ( $\geq 2.0\text{m}$ )
  - Never remove any fixed part of the appliance to make any internal adjustment avoiding electric shock. If the supply cord, the lamp, or other part of appliance is damaged, the manufacturer, its service agent or similarly qualified persons must replace it in order to avoid a hazard.
  - Unplug the appliance before cleaning. Use suitable plastic brush to clean the high voltage metal grid and throw away the bodies of insects on the collection tray every week.
  - The insect killer is to be kept out of reach of children.
-  **Dangerous voltage**
- Check the local voltage before working. Do not intend to touch the internal high voltage grids during using because of electric shock danger. Never put metal objects inside the grids while working. Be sure to cut off electricity when cleaning and repairing the machine.
  - No touching the high-voltage grid by fingers or metal.
  - No washing by water, no placing in the rain.
  - No use in inflammable and/or explosive locales and alike.

- No suitable use in garages, stables and alike.
- Repair should be carried out by the manufacturer or qualified electricians.
- Make sure that your local voltage and frequency should be suitable for the machine.
- Delay time between disconnecting the appliance and accessing the grid is at least 10 s.

### Environment friendly disposal

 You can help protect the environment!

Please remember to respect the local regulations: hand in the non-working electrical equipments to an appropriate waste disposal centre.

 The packaging material is recyclable. Dispose of the packaging in an environmentally friendly manner and make it available for the recyclable material collection-service.

Rated voltage: 220-240V~

Rated frequency: 50-60Hz

